

Atomic LED - Maintenance Schedule

Maintenance schedule vers. 1.0.0 -
Level 1

Part description		Total lamp hours																						
		500 hrs	1000 hrs	1500 hrs	2000 hrs	2500 hrs	3000 hrs	3500 hrs	4000 hrs	4500 hrs	5000 hrs													
	Front Lens 1)		Contact Martin Professional Aps		C		Contact Martin Professional Aps		C		Contact Martin Professional Aps													
	Back Light LED strips				I				I															
	Reflectors																							
	LED Lens																							
	LED Board																							
BACK SIDE	SMPS		Contact Martin Professional Aps				Contact Martin Professional Aps				Contact Martin Professional Aps													
	Base fans	C/SC		C/SC	C/SC	C/SC		C/SC	C/SC	C/SC														
	Filters			C	C	C		C	C	C														
	User Interface																							
	Heat sink																							
	Wireset																							
	Fixture software																							
Technician skill level		1	2	1	1	1	2	1	1	1	2													

Conditions

Ambient temperature	40°C
Voltage / frequency	Within specified range for the product

Code

I	Inspect
R	Replace
C	Clean
L	Lubricate
A	Adjust
SC	FAN Self clean
U	Update

1)
Only cleaning on the outside.
Important! Do not use concentrated alcohol solutions, abrasive products or solvents to clean the lens. If wiping with a soft, lint-free cloth dampened with distilled water is not effective, dampen the cloth with distilled water containing 20% isopropyl alcohol in solution.